

1. Lift the short end
2. Split with a set chisel

YOU WILL NEED:

- Set chisel (blunt end)
- Hammer

## 1. Lift the short end

Place something under the short end of the slate brick to create tension, making it easier to split where you place the chisel.

Ensure the slate brick remains stable.

## 2. Split with a set chisel

Strike the set chisel with a few short, precise blows until the slate brick splits.