

1. Apply the Grease Remover Paste
2. Remove Dried Residue
3. Clean

YPU WILL NEED

- Akemi Oil and Grease Remover Paste
- Brush or spatula
- Akemi Stone Cleaner (optional)

1. Apply the Grease Remover Paste

Ensure the Surface is Completely Dry. Recommended temperature: approximately 5 to 25°C (41 to 77°F).

Apply a layer at least 1-2 mm thick with a brush or spatula. The paste is creamy and easy to apply.

Allow the paste to dry.

2. Remove Dried Residue

Scrape or Brush Off the Dried Paste

For very intense staining, you may need to repeat the treatment.

3. Clean

It may be beneficial to clean the slate surface with a stone cleaner (e.g., Akemi Steinrens) at the end.

TIP: If you have slate under your grill or another area prone to oil spills, we recommend impregnating the surface to prevent stains in the first place. Impregnation is a quick and easy process — see how to impregnate slate [here](#).