

1. Application
2. Waiting time
3. Rinse

#### YOU WILL NEED

- Akemi Rust Remover
- Brush and optional plastic wrap, etc.
- Natural-bristle brush

## 1. Application

The surface must be completely dry.

Apply the product undiluted with a brush.

Tip: To avoid renewed rust formation in untreated areas and/or color differences, it's recommended to treat the entire stone surface.



## 2. Waiting time

Let the product sit for up to 24 hours, depending on the need.

Avoid letting the surface dry out — cover it with plastic wrap or similar if necessary.

## 3. Rinse

Use a natural-bristle brush if needed, then thoroughly rinse with water until all rust remover residue is gone.

Repeat the treatment if necessary when the surface is completely dry again.

Tip: Consider sealing the surface to protect the stone from water penetration, which can lead to renewed rust formation.

Check out this guide for how to clean slate indoors, as well as how to clean slate outdoors and remove all types of stains.