


1. Score a groove
2. Mark the back side
3. Tap with a set chisel

WHAT YOU'LL NEED:

- Scriber or similar tool
- Hammer
- Set chisel


## 1. Score a groove

Score a 1-2 mm deep groove using a scriber or similar tool.



## 2. Mark the back side

Mark the back side of the slate, aligning with where the groove is, and make a clear marking.



## 3. Tap with a set chisel

Place something under the short end of the slate (like the scriber or a plank) to create tension in the slab. Ensure it is stable. Tap along the marking on the back of the slate with a set chisel until the slate splits.

